

## Software Update via USB for SRT 8500

The following manual describes the procedure for a software update at your receiver via your PC and portable USB device.

### Hardware Requirements:

- Windows PC or other operating system with USB or USB 2.0 port. Other systems might require different procedures.
- External USB storage device (USB memory stick, HDD) formatted in FAT or FAT32 file system

Note: Please check/ensure that power consumption of your USB device is not higher than 5 V/500 mA. In case the power consumption is higher, please use a corresponding line adapter before connecting to your receiver, otherwise the usage of such a USB device could damage your receiver.

### Procedure at PC:

1. Save the file in a folder of your choice. Unpack the file to this folder (right mouse click: "Unpack here..." or double click -> select "Unpack to", then choose corresponding folder to save the files).
2. Then connect your USB device to an according slot of your PC. Usually your PC shows a message that a new hardware is found/connected (removable disk).
3. Extract the "MAIN\_DTT1609.SDL" file from the downloaded package to the root directory of the connected USB device.
4. Remove the USB device from your PC by pressing the right mouse button at task bar to "Safely remove hardware" in order to avoid any problems.

### Procedure at Receiver:

Switch ON your receiver and connect the USB device with the stored software to the connector at the receiver. After the USB device has been successfully detected, you can perform the software update according to the following steps:

1. Press **MENU** button to enter Main Menu. Select *Tools* with the ◀▶ buttons and press **OK** to enter.
2. Afterwards select *Upgrade by USB* with the ▲▼ buttons and press **OK** to enter the submenu.
3. You are asked to enter the password. Enter the correct password (the default password is 0000) and press **OK**.
4. Now the receiver will automatically start the download of the software. PLEASE WAIT until this process is finished and the receiver did automatically reboot.

**After the update the receiver restarts automatically! During this process NEVER disconnect the receiver from the main, the USB device or switch the power OFF! This can damage your receiver and warranty will void!**